

## **Brownell LIQUID LOK**

Brownell's Liquid Lok will enhance and increase the longevity of bowstring serving strings. Liquid Lok will help prevent the separation of servings over cams. Liquid Lok is adaptable to all serving string material. Liquid Lok contains no hazardous materials\*.

### Application

1. Burnish section of the bowstring to be serviced.
2. Apply 2 to 3 drops of Liquid Lok to coat section of bowstring to be served.
3. Smooth out application as needed.
4. Serve the bowstring and tie off.
5. Apply 1 to 2 drops of Liquid Lok to each end of the serving. Smooth out application over completed serving
6. Allow finished bowstring to air dry for at least 1 hour before using. Overnight drying preferred to obtain maximum bonding of Liquid Lok.

Note: Once a serving has been lubricated with CAM EZ, Liquid Lok cannot be applied

The use of rubber or latex gloves is advised.

Do not ingest. If accidentally ingested, Call a physician.

Avoid contact with eyes. In case of contact, immediately flush eyes with plenty of water.

Call a physician.

Customer Service/ Product Information 860-873-8625.

\*Hazardous as defined under the criteria of the Federal OSHA Hazard Communications standard 29 CFR 1910.1200